

PART NUMBER	DESIGNATION	NATO	CONDITION	QTY
0268075020	ASTAZOU III C2		OH	7
0268075021	ASTAZOU III C2		RD	7
0268075022	ASTAZOU III C2		RP	7
0268075023	ASTAZOU III C2		AR	7
319A63-10-133	RING CENTERING	1615-14-359-1662	NS	41
341A-31-4120-90	BLANK	SANS NATO	NS	1
341A-98-2009-27	DOG	1730-14-470-9327	NS	16
341A07-1633	MODIF S 484	SANS NATO	NS	1
341A07-1979	S603	SANS NATO	NS	33
341A07-2406-71	TELRAD ENCODEUR	SANS NATO	NS	6
341A07-2448-71	JUPITER PLUG	5975-14-456-7880	NS	5
341A07-2678-71	AUTO PILOT CONTROL	1680-14-520-1345	NS	1
341A07-2712-71	CHRONOMETER MODIF	1680-14-521- 0102	NS	58
341A07-2712-71	CHRONOMETER MODIF	1680-14-521- 0102	NS	30
341A07-7096	MODIF S 518	SANS NATO	NS	2
341A07-7104-72	MODIF S 637	SANS NATO	NS	9

341A07-7110-71	ROTOR BRAKE SUPPRESSOR	1615-14-449-2065	NS	4
341A08-1452-20	COLAR	1560-14-377-2450	NS	1
341A08-1869-0251	ANTI SANDS BLAST KIR REINFORCES	8030-14-582-6928	NS	48
341A08-1869-0251	ANTI SANDS BLAST KIR REINFORCES	8030-14-582-6928	NS	24
341A08-2238-20	GLASS FILTER	1680-14-477-1710	NS	1
341A08-2350-00	CONTROL INST SHOOT	1560-14-463-4918	NS	5
341A09-1005-02	BAND PLOYU	9390-14-484-2770	NS	4
341A09-1005-02	BAND PLOYU	9390-14-484-2770	NS	4
341A09-1005-02	TAPE PU	9390-14-484-2770	NS	1
341A09-1051-02	GUSSET RH	1560-14-379-0750	NS	1
341A11-004-06	BLADE		AR	1
341A11-0040-02	BLADE	1615-14-350-5751	AR	1
341A11-0040-04	BLADE	1615-14-349-1619	AR	17
341A11-0040-05	BLADE	1615-14-453-3665	AR	21
341A11-0040-07	BLADE	1615-14-519-7883	AR	4
341A11-1036-01	BEARING	1560-14-490-0160	NS	3
341A11-1055-01	EXTRACTOR	1615-14-336-3812	NS	2

341A11-1059-20	BANDE PU	8010-14-569-3852	NS	46
341A11-1059-20	BANDE PU	8010-14-569-3852	NS	20
341A11-1059-20	BANDE PU	8010-14-569-3852	NS	13
341A13-1011-20	CLAMP	5340-14-342-9944	NS	2
341A13-1014-20	BOLT		NS	2
341A13-1017-00	BUSH RUBBER		NS	27
341A13-1017-20	RING	5365-14-317-9206	NS	3
341A13-1017-20	BUSH	5365-14-317-9206	NS	89
341A13-1017-20	RING	5365-14-317-9206	NS	157
341A13-1017-20	BUSH	5365-14-317-9206	NS	18
341A13-1017-20	BUSH REUBLER	5365-14-317-9206	NS	20
341A13-1018-20	WASHER	5310-14-317-9207	NS	67
341A13-1023-21	BUSH	3120-14-336-3857	NS	3
341A13-1024-20	WASHER	5310-14-317-9208	NS	2
341A13-1025-20	WASHER	5330-14-317-9210	NS	6
341A13-1028-20	SCREW	5306-14-317-9211	NS	4
341A14-0010-04	STABILIZER,VERTICAL LH	1560-14-336-3882	NS	1

341A14-0010-23	SHIM PEEL		NS	10
341A21-1010-02	PANEL ASSY		NS	50
341A21-1015-01	DOOR ASSY		NS	3
341A21-1041-20	PIN		NS	5
341A21-1042-20	PIN HINGE		NS	9
341A21-1103-01	FLOOR FOOT REST.		NS	1
341A21-1108-23	PROTECTIVE		NS	9
341A21-1108-24	PLATE RH		NS	9
341A21-1112-20	BRACKET		NS	5
341A21-1127-00	PLATE		NS	8
341A21-1134-20	TAB		NS	16
341A21-1166-21	CUP		NS	5
341A21-1856-00	GUIDE ASSYE CABLE		NS	1
341A21-5013-20	INSERT	1560-14-300-9770	NS	30
341A21-5016-20	INSERT		NS	7
341A22-007-04	BELT		NS	2
341A22-1002-22	SHIM		NS	64

341A22-1003-54	BLOCK		NS	2
341A22-1008-01	FITTING REAR RH		NS	2
341A22-1016-20	FITTING	5340-14-286-4610	NS	3
341A22-1016-22	FITTING LH		NS	2
341A22-1016-23	FITTING RH		NS	2
341A22-1018-01	COVER	1560-14-286-4717	NS	3
341A22-1020-29	CLIP		NS	15
341A22-1021-20	FITTING		NS	44
341A22-1024-0101	ENS,CADRE		NS	1
341A22-1025-00	FITTING ASSY		NS	2
341A22-1036-03	FOOT STEP RIGHT	1560-14-296-1212	NS	7
341A22-1036-03	FOOT STEP RIGHT	1560-14-296-1212	NS	2
341A22-1044-01	CASING GROUNDING CONNECTOR		NS	5
341A22-1051-20	FLANGE		NS	5
341A22-1058-00	FITTING		NS	6
341A22-1063-21	INSERT		NS	13
341A22-1063-25	INSERT		NS	7

341A22-1110-00	FITTING CENTRAL		NS	1
341A22-1120-03	PANEL ASSY ACCES		NS	1
341A22-1121-21	HINGE		NS	1
341A22-5002-20	BUSH		NS	10
341A23-1000-33	DOOR		NS	1
341A23-1000-34	STIFFENER		NS	3
341A23-1000-36	STIFFENER		NS	3
341A23-1014-07	SUPPORT STABILIZER		NS	3
341A23-1015-20	BLOCK		NS	1
341A23-1016-02	FAIRING REAR		NS	1
341A23-1025-20	SUPPORT THREADED		NS	18
341A23-1102-36	DOUBLEUR		NS	4
341A23-1106-01	FAIRING LOWER		NS	1
341A23-1110-20	RIB		NS	1
341A23-1112-00	RIB		NS	1
341A23-1123- 0151	SHROUD ASSY TAIL ROTOR		NS	11
341A23-1131- 2001	RIB		NS	8

341A23-1138-25	SPLICE		NS	1
341A23-1143-20	SHIM PEEL		NS	5
341A23-1143-21	SHIM PEEL		NS	2
341A24-1001-00	SUPPORT		NS	1
341A24-1003-20	STOP FIXED LH		NS	1
341A24-1004-20	O'RING		NS	9
341A24-1004-20	STOP RUBBER		NS	12
341A24-1004-20	STOP RUBBER		NS	10
341A24-1011-20	SPACER		NS	120
341A24-1015-20	PLATE	5340-14-286-4754	NS	6
341A24-1015-20	PLATE	5340-14-286-4754	NS	29
341A24-1015-20	PLATE	5340-14-286-4754	NS	6
341A24-1017-00	CLEVIS ATTACHMENT		NS	5
341A24-1018-01	ROD		NS	1
341A24-1039-20	HINGE		NS	1
341A24-1042-20	SUPPORT		NS	6
341A24-1043-00	SUPPORT		NS	3

341A24-1050-00	LOCK ASSY		NS	1
341A24-1050-00	LOCK ASSY		NS	10
341A24-1050-00	LOCK ASSY		NS	2
341A24-2317-10	CABLE		NS	14
341A24-5140-20	PIN		NS	2
341A25-100-2137	COVER STRIP RH		NS	5
341A25-1000-08	SEAL DOOR LH		NS	3
341A25-1000-09	STRIP COVER		NS	2
341A25-1000-09	STRIP COVER	5330-14-417-1640	NS	2
341A25-1000-09	STRIP COVER	5330-14-417-1640	NS	1
341A25-1000-09	STRIP COVER	5330-14-417-1640	NS	104
341A25-1000-10	STRIP COVER		NS	2
341A25-1000-24	STRIP COVER	1560-14-285-4800	NS	21
341A25-1000-25	BRACKET		NS	2
341A25-1000-29	COVER TIP		NS	2
341A25-1000-30	COVER TIP		NS	2
341A25-1000-34	STRIP COVER		NS	2

341A25-1000-3801	COVER TIP		NS	14
341A25-1000-39	PLATE FISH		NS	4
341A25-1000-41	PLATE FISH		NS	12
341A25-1000-48	TAB ATTACHING	5340-14-287-9317	NS	4
341A25-1002-33	COVER STRIP RH		NS	9
341A25-1004-72	SPACER		NS	3
341A25-1023-20	COVER		NS	6
341A25-1025-20	PEEL SHIM		NS	18
341A25-1027-20	HINGE HUPPER		NS	2
341A25-1029-20	STOP RUBBER	1560-14-287-9307	NS	80
341A25-1029-20	STOP RUBBER	1560-14-287-9307	NS	48
341A25-1029-20	STOP RUBBER	1560-14-287-9307	NS	50
341A25-1029-20	STOP RUBBER	1560-14-287-9307	NS	2
341A25-1029-20	STOP RUBBER	1560-14-287-9307	NS	6
341A25-1030-00	BATTERY TRAP		NS	9
341A25-1031-14	PANEL ASSY,SLIDING LH		NS	1
341A25-1040-03	TAG FRAME		NS	43

341A25-1041-01	SUPPORT		NS	4
341A25-1041-28	JUMPER	5340-14-399-3661	NS	2
341A25-1041-30	WASHER		NS	36
341A25-1051-20	ROD,UPPER		NS	2
341A25-1052-20	ROD LOWER		NS	3
341A25-1052-20	ROD LOWER		NS	2
341A25-1054-20	SCREW		NS	45
341A25-1065-20	GUIDE		NS	1
341A25-1065-20	GUIDE		NS	4
341A25-1066-20	TIGE		NS	1
341A25-1066-23	ROD LINK		NS	93
341A25-1070-33	COVER TIP		NS	4
341A25-1070-3801	STRIP COVER		NS	12
341A25-1081-00	SKIN LOWER LH	1560-14-286-4622	NS	1
341A25-1083-00	GRIP HANDLE INNER		NS	3
341A25-1086-00	TUBE		NS	11
341A25-1094-21	AXE		NS	5

341A25-1094-23	PIN		NS	1
341A25-1094-23	PIN		NS	1
341A25-1103-21	STOP		NS	25
341A25-1105-20	1/2 LYRE		NS	22
341A25-1117-21	CATCH		NS	52
341A25-1135-21	SEAL		NS	0
341A25-1135-22	SEAL		NS	8
341A25-1138-20	STOP		NS	41
341A25-1146-00	GUTTER LEFT		NS	1
341A25-1164-22	RECEPTACLE LH		NS	1
341A25-1200-21	BRACKET ANGLE		NS	4
341A25-1226-01	BLANKING ASSY		NS	2
341A25-1226-01	BLANKING ASSY CAP		NS	1
341A27-1113-00	LOCKING BLADE		NS	1
341A27-1131-20	SPRING DEFLEXION		NS	2
341A27-1211-00	SHAFT ASSY COUPLING		NS	1
341A27-1216-20	STOP SCREW		NS	9

341A27-1218-20	STICK CONNECTION		NS	1
341A27-1220-0001	CYCLIC PITCH STICK COPILOT CABLED		AR	3
341A27-1220-0151	STICK ASSY CYCLIC CO PILOT		NS	1
341A27-1220-0753	STICK ASSY CYCLIC COPILOT		NS	1
341A27-1225-20	BOOT		NS	2
341A27-1227-20	BUSH	5365-14-287-2556	NS	53
341A27-1239-20	FRICITION		NS	1
341A27-1311-20	HING STICK FOOT	1680-14-287-2574	NS	1
341A27-1336-00	PROTECTION BOX		NS	4
341A27-1337-01	FOOT STICK		NS	6
341A27-1366-20	SCREW		NS	33
341A27-1368-20W	BOOT	1680-14-289-3888	NS	4
341A27-1368-20W	BOOT	1680-14-289-3888	NS	12
341A27-1369-00	PLATE LOCKING		NS	12
341A27-1412-20	WASHER LOCK		NS	10
341A27-1440-01	END ASSY SWITCHING		NS	1
341A27-1450-00	BEARING ASSY		NS	1

341A27-1453-20	STUD		NS	5
341A27-1454-20	HALF BUSH	3120-14-287-9257	NS	17
341A27-1478-20	BODY		NS	10
341A27-1510-32	BUTTON		NS	6
341A27-1515-20	SCREW		NS	2
341A27-1516-21	BOLT		NS	2
341A27-1516-22	SCREW		NS	19
341A27-1546-03	BELLCRANK ASSY		NS	14
341A27-1619-00	LEVER ASSY	1680-14-287-2622	NS	27
341A27-1620-00	LEVER ROLL CONTROL	1680-14-287-2623	NS	43
341A27-1714-01	BELL CRANK ASSY		NS	2
341A27-1721-20	SPACER	5365-14-287-2632	NS	17
341A27-1734-00	ROD ASSY		NS	2
341A27-1812-20	SPACER	5365-14-257-2653	NS	78
341A27-1816-01	QUADRANT ASSY REAR		AR	8
341A27-1855-00	SUPPORT ASSY		NS	2
341A27-1859-20	HALF GUIDE		NS	2

341A27-1859-20	HALF GUIDE		NS	7
341A27-1866-21	SPACER		NS	11
341A27-1910-0001	ROD ASSY ADJUSTABLE		NS	9
341A27-1913-00-01	ROD		NS	14
341A27-1915-00-01	ROD		NS	11
341A27-1916-00	ROD		NS	2
341A27-1916-0001	ROD		NS	11
341A27-1917-0001	ROD		NS	4
341A27-1917-0001	ROD		NS	8
341A27-1918-0101	ROD ASSY		NS	1
341A27-1918-0101	ROD		NS	1
341A27-1918-0101	ROD		NS	1
341A27-1918-0101	ROD		NS	1
341A27-1919-0001	HALF ROD		NS	6
341A27-1919-0001	HALF ROD		NS	1
341A27-1919-0101	HALF ROD		NS	23
341A27-1919-0201	HALF ROD ASSY		NS	2

341A27-1931-00	CABLE AR BLUE		NS	2
341A27-1931-00	CABLE		NS	2
341A27-1933-00	CABLE AR RED		NS	2
341A27-5038-21	ROLLER		NS	20
341A27-5047-20	WASHER		NS	15
341A27-5059-20	SUPPORT PACKING		NS	35
341A27-5077-03	LEVER ASSY RH		NS	1
341A27-5077-03	LEVER ASSY		NS	2
341A27-5083-20	SPRING		NS	15
341A27-5102-21	LEVER		NS	5
341A27-5103-20	SPINDLE FOOTREST		NS	3
341A27-5121-21	STOP		NS	5
341A27-5130-24	PLATE FRICTION		NS	5
341A27-5130-24	PLATE FRICTION		NS	2
341A27-5130-25	PLATE FRICTION RH		NS	10
341A27-5200- 0001	ROD		NS	1
341A31-0020-01N	HUB ASSY MAIN ROTOR		OH	1

341A31-0020-01N	HUB ASSY MAIN ROTOR		RP	1
341A31-0020-01N	HUB ASSY MAIN ROTOR		AR	1
341A31-1016-20	HOSE		NS	1
341A31-1208-22	STOP		NS	5
341A31-4110-23	SPIGOT		NS	8
341A31-4110-25	SCREW SPECIAL	5305-14-287-9199	NS	12
341A31-4112-31	SCREW	5305-14-285-7462	NS	100
341A31-4124-21	RING		NS	1
341A31-4126-00	BEARING		NS	4
341A31-4126-00	BEARING		NS	1
341A31-4126-00	RETAINER ASSY BEARING		NS	3
341A31-4141-00	SPACER		NS	13
341A31-4156-06	TRUNNION ASSY		NS	2
341A31-4164-00	BEARING		NS	1
341A31-4174-20	WASHER		NS	11
341A31-4174-20	WASHER		NS	5
341A31-4175-20	TANK		NS	3

341A31-4179-20	VERNIER		NS	4
341A31-4180-21	PLATE BASE		NS	6
341A31-4181-02	BOLT		NS	4
341A31-4183-20	BOLT		NS	2
341A31-4184-20	PIN		NS	1
341A31-4184-20	PIN		NS	4
341A31-4184-20	PIN		NS	2
341A31-4185-20	BOLT		NS	1
341A31-4186-20	BOLT		NS	1
341A31-4186-20	BOLT		NS	6
341A31-4208-24	STOP		NS	3
341A31-4208-24	STOP		NS	5
341A31-4212-202N	SHIM THICKNESS 1,7		NS	13
341A31-4217-22	PLUG		NS	4
341A31-4223-20	RESTRAINT		NS	6
341A31-4228-23	PIN TORSION BAR		NS	5
341A31-4228-23	PIN TORSION BAR		NS	12

341A31-4237-22	BOLT TORSION BAR		NS	1
341A31-4243-00	SCISSORS,UPPE R		NS	1
341A31-4243-00	SCISSORS,UPPE R		NS	1
341A31-4244-00	LINK		NS	1
341A31-4262-22	BUSH		NS	3
341A31-4266-03	SLEEVE ASSY		NS	1
341A31-4273-23	RING		NS	5
341A31-4273-23	BUSHING		NS	1
341A31-4275-20	SEAL HOLDER		NS	2
341A31-4275-20	HOLDER SEAL		NS	1
341A31-4286-20	BALL BEARING		NS	1
341A31-4286-20	BALL BEARING		NS	3
341A31-4288-21	LOCKING WASHER		NS	6
341A31-4289-21	BUSH		NS	2
341A31-4291-21	RING		NS	1
341A31-4292-21	SPACER		NS	1
341A31-4292-21	SPACER		NS	1

341A31-4292-21	BRACE		NS	4
341A31-4293-20	SPACER		NS	3
341A31-4295-00	GUIDE SWASHPLATE		NS	9
341A31-4301- 222A	SHIM		NS	9
341A31-4301- 222B	SHIM THICKNESS 1,05		NS	5
341A31-4301- 222C	SHIM THICKNESS 1,10		NS	9
341A31-4301- 222D	SHIM THICKNESS 1,5		NS	5
341A31-4301- 222E	SHIM THICKNESS 1,20		NS	7
341A31-4301- 222F	SHIM THICKNESS 1,25		NS	7
341A31-4301- 222G	SHIM THICKNESS 1,3		NS	7
341A31-4301- 222H	SHIM THICKNESS 1,35		NS	8
341A31-4301- 222J	SHIM THICKNESS 1,4		NS	9
341A31-4301- 222K	SHIM THICKNESS 1,45MM		NS	8
341A31-4301- 222P	SHIM THICKNESS 0,90MM		NS	15
341A31-4301- 222Q	SHIM		NS	14
341A31-4305-20	THRUST BUSHING		NS	3
341A31-4311-00	BOOT	1615-14-363- 7755	NS	2

341A31-4315-00	BOX		NS	2
341A31-4328-00	COMPASS BRANCH		NS	2
341A31-4902-01	BEARING	3110-14-317- 9322	NS	1
341A31-4902-01	BEARING	3110-14-317- 9322	NS	1
341A31-4902-01	BEARING	3110-14-317- 9322	NS	1
341A31-4902-01	BEARING	3110-14-317- 9322	NS	3
341A31-4903-01	BEARING	3110-14-317-9323	NS	1
341A31-4903-01	BEARING	3110-14-317-9323	NS	5
341A31-4903-01	BEARING	3110-14-317-9323	NS	1
341A31-4905-22	COVER DUST	5330-14-359-1598	NS	1
341A31-4905-22	COVER DUST	5330-14-359-1598	NS	13
341A31-4906-20	SPACER	5365-14-349-1658	NS	15
341A31-4906-23	WASHER DU	3120-14-349-1660	NS	1
341A31-4907-00	HOSE	4720-14-286-4986	NS	18
341A31-4907-00	HOSE	4720-14-286-4986	NS	12
341A31-4907-00	HOSE	4720-14-286-4986	NS	28
341A31-4907-00	HOSE	4720-14-286-4986	NS	8

341A31-4907-00	HOSE	4720-14-286-4986	NS	6
341A31-4907-00	HOSE	4720-14-286-4986	NS	45
341A31-4907-00	HOSE	4720-14-286-4986	NS	5
341A31-4907-00	HOSE	4720-14-286-4986	NS	20
341A31-4907-00	HOSE	4720-14-286-4986	NS	3
341A31-4907-00	HOSE	4720-14-286-4986	NS	2
341A31-4909-00	BAG NEEDLES		NS	47
341A31-4912-22	SEAL		NS	1
341A31-4912-22	SEAL		NS	10
341A31-4912-22	SEAL		NS	1
341A31-4913-22	SEAL LIP		NS	3
341A31-4913-22	SEAL LIP		NS	4
341A31-4917-21	BUSH		NS	50
341A31-4917-22	BUSH SEALING	5330-14-378-8591	NS	6
341A31-4918-21	BUSH SEALING		NS	39
341A31-4918-21	BUSH SEALING		NS	1
341A31-4921-21	SEAL		NS	4

341A31-4928-25	SCREW SNAP		NS	12
341A31-4928-25	SCREW SNAP		NS	10
341A31-4928-25	SCREW	5325-14-338-4858	NS	6
341A31-4928-25	SCREW , SNAP	5305-14-338-4858	NS	6
341A31-4928-85	SCREW	5305-14-338-4858	NS	19
341A32-1012-20	KNOB		NS	11
341A32-1019-20	SPACER	5365-14-287-2707	NS	5
341A32-1049-20	HOUSING SIGHT GLASS		NS	10
341A32-1058-20	WASHER		NS	25
341A32-1062-34	STUD		NS	11
341A32-1078-20	SHIM		NS	5
341A32-1081-20	OIL INLET UNION		NS	5
341A32-1085-21	SEAL	5330-14-391-4151	NS	4
341A32-1085-21	SEAL	5330-14-391-4151	NS	8
341A32-1085-21	SEAL SIGHT OIL	5330-14-391-4151	NS	20
341A32-1085-21	SEAL SIGHT OIL	5330-14-391-4151	NS	6
341A32-1085-21	SEAL SIGHT OIL	5330-14-391-4151	NS	4

341A32-1085-21	SEAL	5330-14-391-4151	NS	38
341A32-1088-20	RING BEARING LOWER		NS	8
341A32-1100-00	CARTRIDGE FILTER		NS	2
341A32-1101-20	WASHER		NS	1
341A32-1102-20	WASHER		NS	1
341A32-1103-21	INSERT		NS	1
341A32-1104-20	ELEMENT FILTER		NS	10
341A32-1105-20	GASKET		NS	2
341A32-1106-20	CIRCLIPS		NS	14
341A32-1110-00	STAINER ASSY		NS	11
341A32-1115-20	STUD		NS	5
341A32-1140-20	WASHER PEEL		NS	24
341A32-1143-21	SHIM		NS	18
341A32-1143-22	SHIM		NS	18
341A32-1143-23	SHIM		NS	6
341A32-1143-24	SHIM		NS	7
341A32-1143-25	SHIM		NS	18

341A32-1143-26	SHIM		NS	26
341A32-1143-27	SPACER		NS	20
341A32-1143-28	SHIM		NS	38
341A32-1143-29	SHIM		NS	8
341A32-1159-20	DEFLECTOR		NS	4
341A32-1163-00	SEAL		NS	2
341A32-1164-00	SEAL		NS	20
341A32-1164-00	SEAL		NS	20
341A32-1164-00	SEAL		NS	21
341A32-1166-00	SEAL		NS	1
341A32-1700-02	BRAKE ASSY ROTOR		NS	1
341A32-1710-02	BODY BRAKE		NS	1
341A32-1710-21	BUSH SHOULDERED	5365-14-289-3878	NS	2
341A32-1711-21	SUPPORT LOWER		NS	1
341A32-1715-20	LEVER		NS	1
341A32-1721-20	SHAFT INTERMEDIATE		NS	2
341A32-1722-21	LEVER CONTROL		NS	2

341A32-1722-21	LEVER CONTROL		NS	1
341A32-1722-22	LEVER CONTROL		AR	1
341A32-1723-23	GUIDE		AR	1
341A32-1730-20	DISC ROTOR BRAKE		NS	4
341A32-1737-20	DEFLECTOR		NS	2
341A32-1761-20	WASHER		NS	17
341A32-1766-20	PLATE ATTACHMENT		NS	3
341A32-1767-20	SPRING RETURN		NS	1
341A32-1785-R1	BUSH REPAIR		NS	6
341A32-1785-R2	BUSH		NS	8
341A32-1793-00	INJECTOR		NS	4
341A32-1799-20	FLANGE TAIL TAKE OFF		NS	2
341A32-1800-20	SEAL LIP		NS	3
341A32-1800-20	SEAL LIP		NS	2
341A32-1800-20	SEAL LIP		NS	4
341A32-1800-20	SEAL LIP		NS	108
341A32-1823-20	SPIGOT		NS	1

341A33-5147-20	PIN		NS	60
341A33-5154-20	PLUG		NS	77
341A33-5154-20	PLUG		NS	8
341A33-5154-20	PLUG		NS	15
341A33-5154-20	PLUG		NS	30
341A33-5154-20	PLUG		NS	11
341A33-5156-20	BUSHING BAR RENFO.		NS	9
341A33-5168-20	BUSHING		NS	22
341A33-5172-20	BEARING SURFACE	1615-14-406- 2503	NS	130
341A33-5172-22	BEARING		NS	4
341A33-5173-20	BEARING	3130-14-543-3682	NS	310
341A33-5405-00	FILTER		NS	43
341A33-5422-20	SPACER		NS	2
341A33-5428-20	WASHER LOCK		NS	5
341A33-5458-20	STUD	5307-14-288-7456	NS	12
341A33-5459-20	STUD		NS	20
341A33-5471-20	DISC STOP		NS	4

341A33-5476-20	WASHER		NS	4
341A33-5477-20	STUD		NS	53
341A33-5521-20	SCREW		NS	6
341A33-5542-20	FLANGE		NS	5
341A33-6001-20	SPACER		NS	5
341A33-6005-20	PLUG		NS	80
341A33-6010-21	SIGHT OIL LEVEL		NS	3
341A33-9654-20	BEARING		NS	1
341A33-9654-20	BEARING		NS	1
341A33-9654-20	BEARING		NS	5
341A33-9654-20	BEARING		NS	6
341A33-9663-20	SEAL LIP		NS	4
341A34-1030-20	BUSH, SHOCKABSORBER		NS	116
341A34-1030-20	BUSH, SHOCKABSORBER		NS	2
341A34-1030-20	BUSH, SHOCKABSORBER		NS	80
341A34-1030-20	BUSH, SHOCKABSORBER		NS	53
341A34-1030-20	BUSH, SHOCKABSORBER		NS	94

341A34-1030-20	BUSH, SHOCKABSORBER		NS	39
341A34-1030-20	BUSH, SHOCKABSORBER		NS	12
341A34-1030-20	BUSH SHOCK ABSORBER		NS	49
341A34-1030-20	BUSH SHOCK ABSORBER		NS	3
341A34-1030-20	BUSH SHOCK ABSORBER		NS	35
341A34-1030-20	BUSH		NS	1
341A34-1031-20	PIN , SHEAR	5315-14-317-9222	NS	5
341A34-1034-20	SLEEVE RUBBER		NS	21
341A34-1034-20	SLEEVE RUBBER		NS	120
341A34-1034-20	SLEEVE RUBBER		NS	6
341A34-1034-20	SLEEVE RUBBER		NS	94
341A34-1103-00	BEARING SUPPORT		NS	12
341A34-1112-21	SCREW		NS	50
341A34-1116-20	PLATE STOP		NS	16
341A34-2051-06	GEAR BOX ASSY INTER.	1615-14-350-5749	NS	1
341A34-2108-21	PLUG		NS	12
341A34-2108-21	PLUG		NS	1

341A34-2113-21	SEAL LIP		NS	10
341A34-2113-21	SEAL LIP		NS	1
341A34-2113-21	SEAL LIP		NS	4
341A34-2118-21	BUSH FRICTION		NS	2
341A34-2148-20	ROD TIE		NS	2
341A34-3100-00	INCLINED DRIVE SHAFT		NS	1
341A35-0106-20	ROLLER		NS	8
341A35-0106-20	ROLLER		NS	169
341A35-0109-20	STOP BEARING		NS	5
341A35-0109-20	STOP BEARING		NS	89
341A35-0109-20	STOP BEARING		NS	22
341A35-0112-22	BUSHING		NS	6
341A35-0117-20	SCREW	5305-14-287-9270	NS	5
341A35-0120-00	SHAFT ASSY SUPPORT	1615-14-287-2740	NS	13
341A35-0140-38	WASHER		NS	5
341A35-0148-21	SCREW		NS	2
341A35-0156-20	BEARING		NS	2

341A35-0156-20	BEARING		NS	4
341A35-0156-20	BEARING		NS	1
341A35-0156-20	BEARING		NS	5
341A35-0156-20	BEARING		NS	4
341A35-0156-20	BEARING		NS	2
341A35-0156-20	BEARING		NS	2
341A35-0156-20	BEARING		NS	4
341A35-0156-20	BEARING		NS	5
341A35-0156-20	BEARING		NS	4
341A35-0158-20	SEAL LIP		NS	7
341A35-0158-20	SEAL LIP		NS	2
341A35-0158-20	SEAL LIP		NS	1
341A35-0158-20	SEAL LIP		NS	1
341A35-0158-20	SEAL LIP		NS	3
341A35-0170-20	PLATE LOCK		NS	16
341A35-0224-22	BEARING	3110-14-415-8068	NS	4
341A35-0224-22	BEARING	3110-14-415-8068	NS	1

341A35-0224-22	BEARING	3110-14-415-8068	NS	1
341A35-0224-22	BEARING	3110-14-415-8068	NS	4
341A35-0224-22	BEARING	3110-14-415-8068	NS	5
341A35-0224-22	BEARING	3110-14-415-8068	NS	1
341A35-0224-22	BEARING	3110-14-415-8068	NS	3
341A35-0224-22	BEARING	3110-14-415-8068	NS	3
341A35-0224-22	BEARING	3110-14-415-8068	NS	5
341A35-0224-22	ROLLING	3110-14-415-8068	NS	1
341A35-0224-22	BEARING	3110-14-415-8068	NS	7
341A35-1102-20	BOLT	1615-14-417-1635	NS	2
341A38-1012-20R1	BUSH REPAIR		NS	1
341A38-1012-26R1	BUSH REPAIR		NS	5
341A38-1024-23	BOLT		NS	3
341A38-1041-37RI	BUSH REPAIR		NS	4
341A38-1049-21	SHIM PEEL		NS	3
341A38-1049-21	SHIM PEEL		NS	14
341A38-1050-21	SCHOKABSORBER	5342-14-317-9340	NS	2

341A38-1050-21	SHOCKABSORBER	5342-14-317-9340	NS	1
341A38-1050-21	SHOCKABSORBER	5342-14-317-9340	NS	4
341A38-1050-21	SHOCKABSORBER	5342-14-317-9340	NS	4
341A38-1050-21	SHOCK ABSORBER	5342-14-317-9340	NS	4
341A38-1050-21	SHOCK ABSORBOR	5342-14-317-9240	NS	5
341A38-1055-06	ROD ASSY ADJUSTABLE		NS	2
341A38-1055-06	ROD ASSY ADJUSTABLE		NS	1
341A38-1055-07	END BEARING		NS	1
341A38-1055-23	NUT		NS	47
341A38-1055-24	NUT		NS	16
341A38-1055-32	NUT TENSION		NS	5
341A38-1087-04	SHANCKLE UPPER	4030-14-359-1614	NS	1
341A38-1087-04	SHANCKLE UPPER	4030-14-359-1614	NS	1
341A38-5000-03	VEE REAR		NS	2
341A38-5000-03	VEE REAR		AR	2
341A38-5001-04	VEE FWD		NS	6
341A41-0136-21	SHIM PEEL		NS	4

341A41-5201-02	TIE BAR REAR		NS	1
341A41-5205-09	PLUG ASSY FWD		NS	4
341A41-5210-20	PLATE SKID REAR		NS	4
341A41-5227-00	FITTING		NS	2
341A41-5231-03	LEG LANDING		NS	3
341A41-5231-04	LEG LANDING		NS	2
341A41-5232-04	ARCH REAR		NS	6
341A41-5276-20	SHIM		NS	4
341A41-5327-20	SCREW	5305-14-428- 2948	NS	15
341A41-5327-20	SCREW		NS	4
341A41-5327-20	SCREW		NS	1
341A50-990-P30	KIR SERVICING CONNECTOR 28 VCC		NS	10
341A51-1003-20	SHOCKABSORBE R	5342-14-296-1331	NS	3
341A51-1003-20	SHOCKABSORBE R	5342-14-296-1331	NS	12
341A51-1003-20	SHOCKABSORBE R	5342-14-296-1331	NS	32
341A51-1003-20	SHOCK ABSORBER	5342-14-296-1331	NS	50
341A51-1003-20	SHOCKABSORBE R	5342-14-296-1331	NS	3

341A51-1003-20	SHOCK ABSORBER	5342-14-296-1331	NS	1
341A52-1001-00	HOSE		NS	4
341A52-1004-03	PIPE		NS	1
341A52-1006-20	SHIM		NS	15
341A52-1007-00	HOSE	4720-14-286-4965	NS	5
341A52-1007-00	HOSE	4720-14-286-4965	NS	8
341A52-1007-00	HOSE	4720-14-286-4965	NS	9
341A52-1007-00	HOSE	4720-14-286-4965	NS	2
341A52-1007-00	HOSE	4720-14-286-4965	NS	5
341A52-1007-00	HOSE	4720-14-286-4965	NS	2
341A52-1007-00	HOSE	4720-14-286-4965	NS	35
341A52-1007-00	HOSE	4720-14-286-4965	NS	11
341A52-1008-00	HOSE	4720-14-286-4960	NS	1
341A52-1008-00	HOSE	4720-14-286-4960	NS	5
341A52-1008-00	HOSE	4720-14-286-4960	NS	1
341A52-1008-00	HOSE	4720-14-286-4960	NS	1
341A52-1008-00	HOSE	4720-14-286-4960	NS	2

341A52-1008-00	HOSE	4720-14-286-4960	NS	1
341A52-1008-00	HOSE	4720-14-286-4960	NS	1
341A52-1015-20	O'RING		NS	17
341A52-5001-20	SUPPORT		NS	12
341A53-1000-00	HOSE	4720-14-296-1337	NS	3
341A53-1000-00	HOSE	4720-14-296-1337	NS	2
341A53-1000-00	HOSE	4720-14-296-1337	NS	1
341A53-1000-00	HOSE	4720-14-296-1337	NS	3
341A53-1000-00	HOSE	4720-14-296-1337	NS	3
341A53-1000-00	HOSE	4720-14-296-1337	NS	55
341A53-1001-00	HOSE	4720-14-296-1338	NS	16
341A53-1002-01	HOSE	4720-14-375-7785	NS	32
341A53-1002-01	HOSE	4720-14-375-7785	NS	30
341A53-1002-01	HOSE	4720-14-375-7785	NS	26
341A53-1002-01	HOSE	4720-14-375-7785	NS	2
341A53-1002-01	HOSE	4720-14-375-7785	NS	5
341A53-1002-01	HOSE	4720-14-375-7785	NS	3

341A53-1002-01	HOSE	4720-14-375-7785	NS	1
341A53-1002-01	HOSE	4720-14-375-7785	NS	1
341A53-1002-01	HOSE	4720-14-375-7785	NS	2
341A53-1002-01	HOSE	4720-14-375-7785	NS	6
341A53-1002-01	HOSE	4720-14-375-7785	NS	2
341A53-1002-01	HOSE	4720-14-375-7785	NS	1
341A53-1003-00	PIPE		NS	6
341A53-1003-02	PIPE		NS	1
341A53-1003-04	PIPE		NS	5
341A53-1004-20	SUPPORT CLEAT		NS	1
341A53-1004-20	SUPPORT CLEAT		NS	9
341A53-1007-21	COVER STRIP	5330-14-286-4981	NS	15
341A53-1010-00	DUCT		NS	1
341A53-1010-00	DUCT		NS	1
341A53-1010-01	DUCT		NS	1
341A53-1013-00	DUCT UPPER		NS	2
341A53-1015-00	HOSE		NS	22

341A53-1015-00	SLEEVE PROTECTION		NS	6
341A53-1015-00	SLEEVE PROTECTION		NS	14
341A53-1015-00	SLEEVE PROTECTION		NS	2
341A53-1015-00	SLEEVE PROTECTION		NS	4
341A53-1015-00	SLEEVE PROTECTION		NS	22
341A53-1015-00	SLEEVE PROTECTION		NS	3
341A53-1016-20	HOSE		NS	20
341A53-1016-2001	HOSE		NS	2
341A53-1018-20	RING RETAINER		NS	2
341A54-0020-01	TUBE		NS	2
341A54-0020-26	HOSE		NS	1
341A54-0020-26	HOSE		NS	2
341A54-0020-26	HOSE		NS	14
341A54-0020-26	HOSE		NS	8
341A54-0020-26	HOSE		NS	1
341A54-0051-22	HALF SHELL LH		NS	4
341A54-1001-00	CONNECTOR INLET P2		NS	11

341A54-1002-04	TUBE		NS	2
341A54-1002-04	TUBE		NS	10
341A54-1010-08	SUPPORT LOWER		NS	35
341A54-1010-09	UPPER SUPPORT		NS	56
341A54-1010-24	REINFORCEMENT		NS	1
341A54-1010-26	DEFLECTOR		NS	5
341A54-1010-26	DEFLECTOR		NS	5
341A54-1010-43	DOUBLER		NS	57
341A54-1011-00	EXHAUST NOZZLE		NS	4
341A54-1014-22	SAFETY PLATE		NS	5
341A54-1502-20	LOOK RH		NS	65
341A54-1502-21	LOOK LH		NS	62
341A54-1504-04	FAIRING ASTAZOU XIV		NS	10
341A55-0020-26	HOSE		NS	1
341A55-1002-20	BASE		NS	1
341A55-1012-20	SLEEVE SEALING		NS	10
341A55-1012-20	SLEEVE SEALING		NS	2

341A55-1012-20	SLEEVE SEALING		NS	1
341A55-1014-20	WASHER	5330-14300-9758	NS	9
341A55-1020-20	GASKET		NS	11
341A55-1020-20	SLEEVE SEALING		NS	11
341A55-1020-20	GASKET		NS	7
341A55-1020-20	GASKET		NS	5
341A55-1020-20	GASKET		NS	11
341A55-1033-42	SHIM		NS	9
341A55-1038-01	PIPE		NS	2
341A55-1065-27	TANK FUEL SELF SEALING		NS	2
341A55-1072-00	PLATE ASSY		NS	1
341A55-1076-20	TIE BAR		NS	4
341A55-1078-00	PLUG		NS	3
341A55-1101-00	TANK FERRY FUEL		NS	4
341A55-1103-00	DRIP TUB ASSY		NS	1
341A55-1116-00	HOSE		NS	4
341A55-1117-00	PIPE ASSY		NS	2

341A55-1128-20	PLUG		NS	2
341A55-1131-21	GASKET		NS	80
341A55-1131-21	GASKET		NS	4
341A55-1131-21	GASKET		NS	17
341A55-1131-21	GASKET		NS	2
341A55-1131-21	GASKET		NS	4
341A55-1131-21	GASKET	5330-14-403-5956	NS	1
341A55-1140-02	SUMP ASSY SELF SEALING		NS	1
341A55-1140-02	SUMP ASSY SELF SEALING		NS	1
341A55-1142-00	SUPPORT ASSY		NS	4
341A55-1201-00	TANK WITHOUT FUEL		NS	1
341A55-1230-00	PIPE ASSY		NS	6
341A55-1230-01	PIPE	4710-14-299-0674	NS	18
341A55-1230-02	PIPE		NS	1
341A55-1230-02	PIPE		NS	1
341A55-1230-05	PIPE		NS	7
341A57-1000-48	TUBE		NS	6

341A57-1000-49	TELEFLEX TUBE		NS	2
341A57-1000-51	CABLE		NS	1
341A57-1000-51	CABLE		NS	1
341A57-1000-51	CABLE TELEFLEX		NS	1
341A57-1000-55	CABLE TELEFLEX		NS	25
341A57-1105-00	LEVER ASSY		NS	1
341A57-1111-20	SETTING PIN		NS	7
341A57-1115-24	LEVER		NS	2
341A57-1131-20	WASHER		NS	10
341A57-1137-00	BELL CRANK ASSY		NS	2
341A57-1143-20	STEP PLATE		NS	8
341A57-1147-00	SUPPORT		NS	16
341A57-1154-20	CAM		NS	1
341A57-1158-20	WASHER		NS	8
341A58-0021-12	BULKEAD UPPER		NS	1
341A58-0021-32	EDGE STRIP		NS	15
341A58-0021-38	EDGE STRIP		NS	9

341A58-0050-0251	FAIRING ENGINE LH		NS	1
341A58-0051-09	BULKEAD LOWER RH		NS	2
341A58-1000-02	CABLE RETAINER		NS	3
341A58-1008-20	FASTENER SNAP LOCKING		NS	18
341A58-1008-20	FASTENER SNAP LOCKING		NS	1
341A58-1008-21	CLEVIS & LEVER		NS	2
341A58-1011-23	STRAP		NS	86
341A58-1014-00	ANGLE BRACKET LOWER		NS	16
341A58-1015-20	SPACER		NS	1
341A58-1019-00	PIPE		NS	16
341A58-1020-20	SLEEVE		NS	24
341A58-1021-00	SCUPPER LH		NS	3
341A58-1022-20	SCUPPER RH		NS	3
341A58-1024-00	ANGLE BRACKET UP RH		NS	19
341A58-1024-02	ANGLE UPPER LH		NS	1
341A58-1050-20	BOOT		NS	9
341A58-1050-20	BOOT		NS	1

341A58-1050-20	BOOT		NS	15
341A58-1051-20	COVER		NS	26
341A58-1051-20	COVER		NS	36
341A58-1068-00	INSPECTION DOOR		NS	9
341A58-1500-01	DAMPER		NS	4
341A58-1501-20	STOP		NS	116
341A58-1501-22	STOP FAIRING ENGINE	5340-14-546-8409	NS	10
341A58-1506-20	HOOK FWD		NS	20
341A58-1506-20	HOOK		NS	3
341A58-1511-20	WASHER PEEL		NS	2
341A61-1150-03	ENSEMBLE		NS	1
341A61-1190-20	REINFORCING		NS	1
341A61-1217-20	GROMMET		NS	12
341A61-1223-20	GROMMET		NS	5
341A61-1224-20	CLAMP		NS	33
341A61-1226-00	BOX ASSY		NS	2
341A61-1232-01	BLOCK TERMINAL 14 DELTA		NS	5

341A61-1232-0105	BLOCK TERMINAL		NS	1
341A61-1239-20	BASE THEARED		NS	12
341A61-1240-20	BASE THREADED		NS	14
341A61-1319-21	CLAMP		NS	6
341A61-1319-21	CLAMP		NS	4
341A61-5018-21	CABLE SUPPORT		NS	30
341A61-990-P30	LOOM 28VDC SOCKET INST		NS	13
341A61-990-P30	LOOM 28VDC SOCKET INST		NS	17
341A62-1100-03	FUSE ASSY		NS	3
341A62-1123-20	ELBOW		NS	2
341A62-1214-00	LOVER ASSY		NS	4
341A62-1391-0001	DOOR ASSY ACCESS		NS	3
341A64-1091-20	BLANKING FIN		NS	6
341A64-1105-00	BRACKET POSITION LIGHT		NS	21
341A64-1107-00	SUPPORT		NS	5
341A64-1167-00	FORMATION LIGHT SUPPORT		NS	1
341A64-1167-00	FORMATION LIGHT SUPPORT		NS	8

341A64-1167-00	FORMATION LIGHT SUPPORT		NS	10
341A64-1178-00	SUPPORT		NS	4
341A64-1178-00	SUPPORT		NS	1
341A64-1188- 0101	LOOM 86L		NS	14
341A64-1195-00	NUTS PLATE		NS	4
341A64-1202-01	BOX		NS	6
341A64-1260-00	PANEL SUPPORT		NS	1
341A64-1261-22	UV PROJECTOR		NS	1
341A64-1266-20	POTENTIOMETRE		NS	1
341A64-1266-21	ENSEMBLE		NS	1
341A64-1268-20	LABEL		NS	1
341A65-2321-02	SUPPORT ANTENNA		NS	2
341A65-2322-20	BRACKET ANGLE		NS	13
341A65-2631-21	SUPPORT		NS	3
341A65-3131-00	SUPPORT FW ASSY		NS	6
341A65-3150-00	BLANKING		NS	1
341A65-3161-00	SUPPORT		NS	2

341A65-4111-00	LOOM ASSY		NS	4
341A65-4111-01	LOOM ASSY		NS	5
341A65-4141-00	PANEL,SUPPORT JACKS		NS	7
341A65-4141-00	PANEL,SUPPORT JACKS		NS	5
341A65-4143-20	SET OF LABELS		NS	1
341A65-9605-00	BLOCK TERMINAL		NS	7
341A65-9609-00	BLOCK ASSY TERMINAL 7 DELTA		NS	17
341A66-1062-04	CONNECTOR ASSY		NS	6
341A66-1082-06	HOSE ASSY		NS	10
341A66-1082-08	HOSE ASSY		NS	1
341A66-1084-00	SUPPORT		NS	2
341A66-1084-20	SUPPORT		NS	39
341A66-1315-00	LOOM ACTUATOR		NS	9
341A66-1315-00	LOOM ACTUATOR		NS	10
341A66-1330-0201	BLANKING		NS	4
341A66-1331-00	SUPPORT INDICATOR		NS	4
341A66-1336-00	CONNECTOR SHUNT		NS	19

341A67-1061-02	COVER		NS	10
341A67-1096-21	PIN		NS	36
341A67-1387-01	ROD		NS	4
341A67-1387-21	ENS.		NS	1
341A68-1068-00	BRAID BONDING		NS	8
341A68-1140-00	SOCKET ASSY		NS	3
341A68-1153-20	STRIP		NS	1
341A68-3620-05	SUPPORT ASSY		NS	3
341A68-3621-00	END PLUG		NS	8
341A68-3747-0001	GYRO COMPAS		NS	1
341A68-3752-23	REINFORCING		NS	1
341A68-3752-24	SUPPORT		NS	1
341A68-3753-20	SUPPORT		NS	1
341A68-3754-20	BRACKET		NS	1
341A68-3792-00	UNIT ASSY		NS	1
341A68-3797-20	COVER		NS	1
341A68-3798-20	PLATE NAME		NS	5

341A68-3800-00	ENSEMBLE BOITIER		NS	1
341A68-3817-00	BOX ASSY SHUNT		NS	1
341A68-3817-00	BOX ASSY SHUNT		NS	2
341A68-9601-20	PLATE LIGHTING	9905-14-421-4019	NS	1
341A69-1229-20	PLATE ASSY BLANKING		NS	3
341A69-1241-01	SUPPORT		NS	4
341A69-1241-01	SUPPORT		NS	1
341A69-1416-20	SUPPORT		NS	1
341A69-1431-00	BRACKET		NS	2
341A69-1431-00	BRACKET		NS	2
341A69-1431-00	BRACKET		NS	2
341A69-1431-00	BRACKET		NS	3
341A72-1011-00	HOSE	4720-14-286- 4876	NS	10
341A72-1011-01	HOSE	4720-14-286- 4876	NS	25
341A72-1011-01	HOSE	4720-14-286- 4876	NS	23
341A72-1011-01	HOSE	4720-14-286- 4876	NS	13
341A72-1011-01	HOSE	4720-14-286- 4876	NS	3

341A72-1011-01	HOSE	4720-14-286-4876	NS	1
341A72-1013-01	PIPE		NS	1
341A72-1015-00	DEFLECTOR ASSY		NS	6
341A72-1019-00	SUPPORT		NS	3
341A72-1020-00	VALVE ASSY HOT AIR		NS	5
341A72-1023-01	DUCT HEATING		NS	2
341A72-1023-01	DUCT HEATING		NS	1
341A72-1024-03	PANEL CLOSING		NS	2
341A72-1025-20	PLATE BLANKING		NS	7
341A72-1027-20	SPACER		NS	5
341A72-1029-22	SPACER		NS	14
341A72-1031-01	HOSE		NS	1
341A72-1031-02	HOSE		NS	10
341A72-1034-01	TUBE		NS	1
341A72-1034-02	TUBE		NS	2
341A72-1035-20	DUCT DEMISTING		NS	9
341A72-1035-20	DUCT DEMISTING		NS	9

341A72-1100-01	HOSE		NS	100
341A72-1102-00	SUPPORT ASSY		NS	5
341A72-1110-01	HOSE		NS	2
341A72-1110-01	HOSE		NS	72
341A72-1110-01	HOSE		NS	82
341A72-1110-01	HOSE		NS	11
341A72-1110-01	HOSE		NS	10
341A72-1110-01	HOSE		NS	54
341A72-1110-01	HOSE		NS	36
341A72-5140-20	PIN		NS	2
341A75-0020-AY51	SWITCH	5930-14-562-7652	NS	1
341A75-1014-12	HOSE		NS	2
341A75-1040-13	PIPE		NS	2
341A75-1040-15	PIPE		NS	1
341A75-1040-15	PIPE		NS	1
341A75-1040-17	PIPE		NS	9
341A75-1040-22	PIPE		NS	2

341A75-1046-00	PIPE		NS	1
341A75-1046-00	PIPE		NS	2
341A75-1046-01	PIPE		NS	1
341A75-1046-02	PIPE		NS	2
341A75-1046-02	PIPE		NS	2
341A75-2008-01	MANI FOLD ASSY		NS	1
341A75-2010-20	MANFOLD		NS	4
341A75-2011-20	HYD CONNECTION		NS	2
341A75-2025-20	PLATE SUPPORT		NS	26
341A75-2032-20	ADAPTOR		NS	7
341A75-2033-20	LOCATING FORK		NS	8
341A75-3012-00	HOSE		NS	1
341A75-3013-00	HOSE		NS	18
341A75-3014-00	HOSE		NS	2
341A75-3015-00	HOSE	4720-14-286-4842	NS	12
341A75-3015-00	HOSE	4720-14-286-4842	NS	32
341A75-5017-20	UNION		NS	2

341A75-5026-20	NUT SPECIAL		NS	2
341A76-1020-08	BELT ASSY PASSENGER		NS	8
341A76-1020-08	BELT		NS	2
341A76-1035-02	GUARD ASSY		NS	1
341A76-1035-02	CARD ASSY		NS	1
341A76-1049-01	SLEEVE PROTECTION		NS	5
341A76-1072-20	WASHER		NS	7
341A76-1166-00	SUPPORT ASSY		NS	7
341A76-1167-20	SILENT BLOCK		NS	9
341A76-1167-20	SILENT BLOCK		NS	9
341A76-1174-02	PANEL LOWER LH		NS	1
341A76-1174-02	PANEL LOWER LH		NS	14
341A76-1175-01	PANEL LOWER		NS	3
341A76-1191-00	BRACKET FOR UPPER KIT		NS	4
341A76-1191-00	BRACKET FOR UPPER KIT		NS	8
341A76-1193-11	SUPPORT		NS	10
341A76-1193-12	SUPPORT		NS	16

341A76-1216-00	PROTECTION COVER		NS	7
341A76-1226-20	PLATE INSULATION		NS	2
341A76-1241-20	WASHER		NS	130
341A76-1242-20	SPACER		NS	10
341A76-1242-21	SPACER		NS	10
341A76-1254-20	BEARING		NS	10
341A76-1255-20	SPRING		NS	44
341A76-1256-20	SHIM		NS	46
341A76-1257-20	JUMPER		NS	60
341A76-1264-20	PLATE LIGHTNING		NS	1
341A76-1265-20	LIGHTING PLATE		NS	1
341A76-1267-25	PLATE ENGRAVED FILT		NS	26
341A76-1267-27	UNBORNED PLATE		NS	126
341A76-1287-01	COVER		NS	13
341A76-1301-20	PELLET		NS	5
341A76-1320-09	HOSE ASSY		NS	1
341A76-1377-21	PLATE MAX		NS	1

341A76-1429-03	INST PANEL COVER		NS	7
341A76-1558-01	DISPLAY PANEL		NS	3
341A76-1593-00	END		NS	1
341A76-2544- 0101	JACK ASSY		NS	1
341A76-5008-00	ATTACH. PLATE		NS	1
341A77-1148-00	BOX BODY		NS	7
341A81-0611-20	FITTING		NS	1
341A81-0630-32	LOCK ASSY LOWER RH		NS	3
341A81-0639-20	COVER STRIP		NS	71
341A81-0640-02	GUIDE ASSY		NS	1
341A81-0640-02	GUIDE ASSY		NS	12
341A81-0641-20	STRIP COVER		NS	2
341A81-0645-00	PIN		NS	22
341A81-1070-20	RING STOP		NS	2
341A81-1076-20	SEAL		NS	3
341A81-1076-20	SEAL		NS	6
341A81-1076-20	SEAL		NS	6

341A81-1076-20	SEAL		NS	2
341A81-1076-20	SEAL		NS	14
341A81-1078-20	SEAL		NS	28
341A81-1083-01	PLATE BLANKING RH		NS	4
341A81-1173-20	SPIGOT		NS	16
341A81-1330-20	BUSH		NS	32
341A81-1331-20	SCREW		NS	16
341A81-1365-21	BLOCK RH		NS	5
341A81-1583-20	LEVER BLOCKING		NS	2
341A81-1584-20	FRICTION PAD		NS	3
341A81-1585-20	SWINGING ARM		NS	3
341A81-1587-20	FITTING		NS	3
341A81-1588-00	GUARD ASSY		NS	3
341A81-1590-00	SUPPORT		NS	4
341A81-1593-00	SUPPORT		NS	9
341A81-1593-21	SCREW		NS	30
341A81-1595-20	SUPPORT		NS	10

341A81-1660-01	PC STIK		NS	5
341A81-1660-01-01	PC STIK		NS	1
341A81-1835-00	SUPPORT		NS	5
341A82-1190-01	TOOL BLADES FOLDING		NS	6
341A82-1190-05	TOOL BLADES FOLDING		NS	2
341A82-4370-00	JET DEFLECTOR ASTAZOU 3		NS	1
341A84-1250-30	SHIM		NS	30
341A84-1261-01	SUPPORT ASSY RH		NS	2
341A84-1262-20	BEARING		NS	11
341A84-1263-00	SUPPORT		NS	2
341A84-1264-00	SUPPORT		NS	2
341A84-1264-00	SUPPORT		NS	1
341A84-1264-02	SUPPORT ASSY LEFT		NS	21
341A84-1264-02	SUPPORT ASSY LEFT		NS	4
341A84-1270-00	GUARD ASSY		NS	2
341A84-1270-20	COVER		NS	3
341A84-1275-20	SHIM		NS	4

341A89-0010-48	BONDING JUMPER		NS	4
341A89-1033-60	CONNECTOR SUPPORT		NS	4
341A91-0027-00	FUSE		NS	5
341A91-0027-31	PIN		NS	20
341A91-0029-11	SLING	4010-14-300-9480	NS	1
341A91-0029-11	SLING	4010-14-300-9480	NS	18
341A91-0042-11	PIN		NS	4
341A91-0042-23	WASHER		NS	23
341A91-0066-11	SLING		NS	2
341A91-0116-03	WHEEL ASSY HANDLING		NS	15
341A91-0116-13	MECHANIS SYSTEM		NS	2
341A91-0116-21	SPACER	3040-14-389-0349	NS	29
341A91-0116-22	BUSHING		NS	27
341A91-0118-01	WEEHL SUPPORT		NS	4
341A91-0130-16	DIABOLO ASSY		NS	1
341A91-2305-11	SUPPORT ASSY REAR		NS	1
341A91-2316-00	LATERAL CABLE ASSY		NS	5

341A91-2317-00	ENS AR. CABLE		NS	5
341A91-3115-00	BLANKING		NS	1
341A91-3115-00	BLANKING FITTING	4920-14-399-3666	NS	21
341A91-3410-00	JIG IGB MOUNTING		AR	1
341A91-4100-00	SHIM		NS	1
341A91-5400-00	SLING ASSY		NS	1
341A91-5400-00	SLING ASSY		AR	1
341A91-5406-11	SCREW		NS	50
341A91-8100- 0171	CRANE MODIF		NS	2
341A92-1085-21	SEAL		NS	6
341A92-1100-00	TAB PROTECTOR		NS	4
341A92-1114-10	MAIN BLADE COVER		NS	43
341A92-1114-10	MAIN BLADE COVER		NS	6
341A92-1116-00	STRAP STOWING MAIN BLADE FOLDED		NS	1
341A92-1116-00	STRAP STOWING MAIN BLADE FOLDED		NS	3
341A92-1116-00	STRAP STOWING MAIN BLADE FOLDED		NS	1
341A92-1120-03	TOOL ASSY BLADES FOLDING	1730-14-478-7950	NS	5

341A92-1126-01	ATTACH.DRAG DAMPER		NS	1
341A92-5405-00	COVER SAND FILTER ASTAZOU		NS	1
341A92-5410-00	BLANKING JET DEFLECTOR		NS	26
341A93-1101-01	LOCK INCIDENCE		NS	3
341A93-1105-00	PIN BLADE		AR	1
341A93-3100-20	PLATE TOWER		AR	1
341A93-3103-20	WRENCH		NS	1
341A93-3106-00	BLACK DOLLY EXTRACTION		NS	1
341A93-3107-20	TOOL		AR	1
341A93-3108-00	EXTRACTOR		AR	1
341A93-3109-00	EXTRACTOR		NS	1
341A93-3110-00	BASE		NS	1
341A93-3111-00	TOOL INSERTING		NS	9
341A93-3111-00	TOOL		AR	1
341A93-3115-00	TOOL		AR	1
341A93-3121-21	INSERTING BLOCK		AR	1
341A93-3123-20	LOCATING TOOL		NS	1

341A93-3210-00	EXTRACTOR		AR	1
341A93-3211-00	TOOL		NS	1
341A93-3212-00	TOOL		AR	1
341A93-3220-00	EXTRACTOR		AR	1
341A93-3221-01	EXTRACTOR		NS	1
341A93-3222-00	WRENCH		AR	1
341A93-3223-00	WRENCH		NS	1
341A93-3225-01	ENS.TAS AND JET		NS	3
341A93-3225-01	TOOL		AR	1
341A93-3225-0121	MODIF		NS	1
341A93-3225-0122	MODIF		NS	1
341A93-3226-00	EXTRACTOR		AR	1
341A93-3227-20	JET EMMANCHEMENT		NS	2
341A93-3303-20	WRENCH		AR	1
341A93-3305-00	TOOL ASSY		NS	7
341A93-3305-00	TOOL		NS	1
341A93-3305-20	BLOCK		NS	14

341A93-3305-20	TAS BLOCK		NS	1
341A93-3307-00	WRENCH		NS	1
341A93-3308-00	EXTRACTOR		NS	1
341A93-3309-00	TOOL		NS	1
341A93-3401-00	EXTRACTOT BEFORE MB S208		NS	4
341A93-3404-00	TOOL		NS	1
341A93-3405-00	EXTRACTOR		AR	1
341A93-3410-00	WRENCH		AR	1
341A93-3412-00	EXTRACTOR		AR	1
341A93-3413-00	EXTRACTOR		AR	1
341A93-3415-20	BLOCK		AR	1
341A93-3418-01	SUPPORT LEVEL		NS	15
341A93-3418-01	SUPPORT LEVEL		NS	1
341A93-3500-00	EXTRACTOR		AR	1
341A93-3501-00	WRENCH		AR	1
341A93-3502-20	JET EMMANCHEMENT		NS	19
341A93-3504-00	TOOL		AR	1

341A93-3505-00	EXTRACTOR		AR	1
341A93-3506-20	DRIFT		AR	1
341A93-3508-01	CYMBLOT		NS	2
341A93-3508-01	TOOL		AR	1
341A93-3510-00	BLOCK HOLDING		AR	1
341A93-3523-00	BLOCK HOLDING		AR	1
341A93-3524-20	THIMBLE		AR	1
341A93-3528-20	MOUNT		AR	1
341A93-3532-00	WRENCH		AR	1
341A93-3533-20	BLOCK HOLDING		AR	1
341A933106-00	EXTRACTOR		AR	1
341A933502-20	DRIFT		AR	1
341A94-1100-00	TAB ADJUSTEMENT		NS	1
341A94-1100-00	TOOL		NS	1
341A94-2710-02	SET OF PINS		NS	1
341A94-2710-10	PIN		NS	45
341A94-2710-10	PIN		NS	4

341A94-2710-11	PIN		NS	38
341A94-2710-11	PIN		NS	1
341A94-2710-11	PIN		NS	50
341A94-2710-11	TOOL ASSY		NS	30
341A94-2710-12	PIN		NS	35
341A94-2710-12	PIN		NS	4
341A94-2710-13	PIN		NS	20
341A94-2710-13	PIN		NS	12
341A94-2710-13	PIN		NS	2
341A94-2721-02	SUPPORT		AR	1
341A94-2722-00	LEVEL SUPPORT		AR	1
341A94-2726-01	SUPPORT		AR	1
341A94-2740-01	SUPPORT GRIP HANDLE		NS	1
341A94-2742-00	DUMMY HANDLE		NS	1
341A94-2744-00	SUPPORT		AR	1
341A94-2746-01	TOOL		NS	1
341A94-2748-00	LEVER CONTROL		NS	1

341A94-2750-00	SUPPORT		NS	1
341A94-3300-01	TOOL KEYWAY CHECKING		NS	1
341A94-3400-01	TOOL		NS	30
341A94-3400-10	MODIFICATION KIT		NS	7
341A94-5400-25	SCREW		NS	20
341A94-5400-54	NUT		NS	8
341A94-5400-55	PAD		NS	8
341A95-0010-01	TOOL		NS	1
341A95-3400-18	CABLE ASSY	4920-14-349-1674	NS	16
341A96-3002-01	DOWN TIME		NS	1
341A96-3010-01	BLANKING CASE		NS	1
341A96-3203-20	BLANKING	5365-14-300-9699	NS	1
341A96-3206-00	MGB UP COVER		NS	6
341A96-3206-00	COVER MGB		NS	1
341A96-3208-20	SHIM		NS	8
341A96-3210-02	BASE		NS	1
341A96-3215-20	BLANKING FILTER		NS	2

341A96-3304-21	BLADE PROTECT		NS	1
341A96-3305-00	TOOL		NS	2
341A96-3305-00	TOOL		NS	1
341A96-3510-01	BLANKING ASSY		NS	1
341A96-5300-00	BLANKING ASSY		NS	1
341A96-5300-00	BLANKING		NS	1
341A96-5500-00	BLANKING		NS	1
341A96-5500-10	CASE		NS	10
341A96-5503-00	OBTURATOR		NS	12
341A96-5503-21	GASKET		NS	24
341A98-2001-00	TOOL		NS	1
341A98-2003-00	TOOL		AR	1
341A98-2004-00	VERNIER COLLAGE TOOL		NS	6
341A98-2005-00	HOLDING TOOL		NS	11
341A98-2005-00	TOOL		NS	1
341A98-2005-15	KIT		NS	2
341A98-2006-20	DRIFT SPINDLE TRUNNION		NS	11

341A98-2006-20	DRIFT		AR	1
341A98-2008-02	JET		NS	1
341A98-2008-02	JET		NS	15
341A98-2008-03	DRIFT		AR	1
341A98-2009-02	EXTRACTOR		AR	1
341A98-2009-26	DOG		NS	1
341A98-2022-10	TOOL		AR	1
341A98-2023-00	EXTRACTOR		NS	1
341A98-2025-20	DUMMY BOX		AR	1
341A98-2026-20	THIMBLE		NS	1
341A98-2027-00	EXTRACTOR		NS	1
341A98-2028-20	WRENCH		AR	1
341A98-2029-21	PIN		NS	1
341A98-2030-20	PIN		NS	1
341A98-2031-01	BONDING TOOL		NS	1
341A98-2034-20	THIMBLE		NS	1
341A98-2036-00	EXTRACTOR		NS	2

341A98-2036-00	EXTRACTOR		NS	1
341A98-2036-01	EXTRACTOR		NS	8
341A98-2036-01	EXTRACTOR		NS	1
341A98-2036-30	EXTRACTOR		NS	6
341A98-2037-20	DRIFT		NS	1
341A98-2038-00	EXTRACTOR		NS	1
341A98-2039-00	TOOL		AR	1
341A98-2040-00	EXTRACTOR		AR	1
341A98-2046-00	HOLDING BASE		NS	2
341A98-2046-01	HOLDING BASE MRP		NS	5
341A98-2054-00	HANDLE		NS	1
341A98-2055-00	HANDLE		NS	1
341A98-3300-00	BLANKING		NS	1
341A98-3308-00	CLIP		NS	1
341A98-3309-01	PIN		NS	1
341AMR134310	ASSY PLATE		NS	3
341AS-1084-BC	KIT MANUT		NS	30

341AS1084BC	MODIF KIT		NS	33
-------------	-----------	--	----	----